HOW TO BUILD YOUR OWN ROGUE GSM BTS FOR FUN AND PROFIT

2016-03-31 | ● #bladerf, #bladerf x40, #bts, #evilbts, #gsm, #gsm hijacking, #gsm intercept, #gsm sniffing, #hacking, #rf, #rogue bts, #yate, #yatebts

The last week I've been visiting my friend and colleque <u>Ziggy</u> in Tel Aviv which gave me something I've been waiting for almost a year, a brand new <u>BladeRF x40</u>, a low-cost USB 3.0 Software Defined Radio working in full-duplex, meaning that it can transmit and receive at the same time (while for instance the HackRF is only half-duplex).

In this blog post I'm going to explain how to create a portable GSM BTS which can be used either to create a private (and vendor free!) GSM network or for **GSM active tapping/interception/hijacking** ... yes, with some (relatively) cheap electronic equipment you can basically build something very similar to what the governments are using from years to perform GSM interception.

I'm not writing this post to help script kiddies breaking the law, my point is that GSM is broken by design and it's about time vendors do something about it considering how much we're paying for their services.



Hardware Requirements

In order to build your BTS you'll need the following hardware:

- A bladeRF x40
- Two Quad-band Cellular Duck Antennas SMA.
- A Raspberry Pi 3 (model 2 and below are too slow).
- An USB battery pack (I'm using a 26800mAh Anker Astro E7).
- A microsd for the RPI >= 8GB.
- Some patience and time ... :)

<u>Software</u>

Let's start by installing the <u>latest Raspbian</u> image to the micrsd card (use the "lite" one, no need for UI ;)), boot the RPI, configure either the WiFi or ethernet and so forth, at the end of this process you should be able to SSH into the RPI.

Next, install a few dependecies we're gonna need soon:

At this point, you should already be able to interact with the BladeRF, plug it into one of the USB ports of the RPI, **dmesg** should be telling you something like:

```
[ 2332.071675] usb 1-1.3: New USB device found, idVendor=1d50, idProduct=6066
[ 2332.071694] usb 1-1.3: New USB device strings: Mfr=1, Product=2, SerialNumber=
[ 2332.071707] usb 1-1.3: Product: bladeRF
[ 2332.071720] usb 1-1.3: Manufacturer: Nuand
[ 2332.071732] usb 1-1.3: SerialNumber: b4ef330e19b718f752759b4c14020742
```

Start the **bladeRF-cli** utility and issue the **version** command:

pi@raspberrypi:~ \$ sudo bladeRF-cli -i							
bladeRF> version							
bladeRF-cli version:	0.11.1-git						
libbladeRF version:	0.16.2-git						
Firmware version:	1.6.1-git-053fb13-buildomatic						
FPGA version:	0.1.2						

bladeRF>

IMPORTANT Make sure you have these exact versions of the firmware and the FPGA, other versions might not work in our setup.

Download the correct firmware and FPGA image.

Now we're going to install Yate and YateBTS, two open source softwares that will make us able to create the BTS itself.

Since I spent **a** lot of time trying to figure out which specific version of each was compatible with the bladeRF, I've created a github repository with correct versions of both, so in your RPI home folder just do:

```
git clone https://github.com/evilsocket/evilbts.git
cd evilbts
```

Let's start building both of them:

a yate
/autogen.sh
/configureprefix=/usr/local
ake -j4
udo make install
udo ldconfig
d
d yatebts
/autogen.sh
/configureprefix=/usr/local
ake -j4
udo make install
udo ldconfig

This will take a few minutes, but eventually you'll have everything installed in your system.

Next, we'll symlink the NIB web ui into our apache www folder:

```
cd /var/www/html/
sudo ln -s /usr/local/share/vate/nib web nib
```

And grant write permission to the configuration files:

You can now access your BTS web ui from your browser:

http://ip-of-your-rpi/nib

Time for some configuration now!

Configuration

Open the /usr/local/etc/yate/ybts.conf file either with nano or vi and update the following values:

Radio.Band=900
Radio.C0=1000
Identity.MCC=YOUR_COUNTRY_MCC
Identity.MNC=YOUR_OPERATOR_MNC
Identity.ShortName=MyEvilBTS
Radio.PowerManager.MaxAttenDB=35
Radio.PowerManager.MinAttenDB=35

You can find valid MCC and MNC values here.

```
Now, edit the /usr/local/etc/yate/subscribers.conf:
```

country_code=YOUR_CONTRY_CODE
regexp=.*

WARNING Using the .* regular expression will make EVERY GSM phone in your area connect to your BTS.

In your NIB web ui you'll see something like this:



Subscribers	BTS Configuration	Call Logs	Outgoing						
GSM	GPRS	Control	Transceiver Tapping Test YBTS						
GSM GSM Advanced									
		Set parameters va	alues for section [gsm] to be written in ybts.conf file.						
		Radio.Band	d EGSM900 : ?						
		Radio.C0	0 #1000: 930.2 MHz downlink : ?						
		Identity.MCC	222 ?						
		Identity.MNC	C 01 ?						
		Identity.LAC	2 1007 ?						
		Identity.CI	667						
		Identity.BSIC.BCC	2 : ?						
		Identity.BSIC.NCC	2 0 : ?						
		Identity.ShortName	e MyEvilBTS ?						
	Radio.PowerMa	nager.MaxAttenDB	3 35 ?						
	Radio.PowerMa	anager.MinAttenDB	3 35 ?						
			Submit Reset						

Enable GSM-Tapping

In the "Tapping" panel, you can enable it for both GSM and GPRS, this will basically "bounce" every GSM packet to the loopback interface, since we haven't configure **any encryption**, you'll be able to see all the GSM traffic by simply tcpdump-ing your loopback interface :D



Subscribers	BTS Configuration	Call Logs	Outgoing			
GSM	GPRS	Control	Transceiver	Tapping	Test	YBTS
	S	et parameters val	ues for section [tapping] to	be written in ybts.co	nf file.	
GSM Capture GSM signaling at L1/L2 interface via GSMTAP Do not leave tapping enabled after finishing troubleshooting. Defaults to no.						
		GPRS	Capture GPRS signaling and tra Do not leave tapping enabled af Defaults to no	ffic at L1/L2 interface via ter finishing troubleshootir	GSMTAP. ng	
		TargetIP	127.0.0.1	?		
					Submit Reset	

Start It!

Finally, you can start your new BTS by executing the command (with the BladeRF plugged in!) :

sudo yate -s

If everything was configured correctly, you'll see a bunch of messages and the line:

Starting MBTS... Yate engine is initialized and starting up on raspberrypi RTNETLINK answers: File exists MBTS ready

At this point, the middle LED for your bladeRF should start blinking.

Test It!

Now, phones will start to automatically connect, this will happen because of the GSM implementation itself:

- You can set whatever MCC, MNC and LAC you like, effectly spoofing any legit GSM BTS.
- Each phone will search for BTS of its operator and select the one with the strongest signal ... guess which one will be the strongest? Yep ... ours :D

Here's a picture taken from my Samsung Galaxy S6 (using the <u>Network Cell Info Lite</u> app) which automatically connected to my BTS after 3 minutes:





From now on, you can configure the BTS to do whatever you want ... either act as a "proxy" to a legit SMC (with a GSM/3g USB dongle) and **sniff the unencrypted GSM traffic** of each phone, or to create a private GSM network where users can communicate for free using SIP, refer to the <u>YateBTS Wiki</u> for specific configurations.

Oh and of course, if you plug the USB battery, the whole system becomes completely portable :)

References and Further Readings

- https://github.com/Nuand/bladeRF/wiki/Setting-up-Yate-and-YateBTS-with-the-bladeRF
- https://z4ziggy.wordpress.com/2015/05/17/sniffing_gsm_traffic_with_hackrf/
- https://z4ziggy.wordpress.com/2015/05/10/ziggys-embedded-bts/
- http://wiki.yatebts.com/index.php/Main_Page

Copyright © 2019 Simone Margaritelli <u>~/</u> | <u>rss</u>